

2001 UNGO REMOTE TRANSMITTER PROGRAMMING

KE106 (SAA003T)

- 1) TURN THE IGNITION "ON"
- 2) PRESS AND HOLD THE OVERRIDE SWITCH
 - THE HORN HONKS 5 TIMES AND LIGHT FLASHES 5 TIMES
 - THE STATUS LED WILL TURN ON SOLID
- 3) WITHIN 2 SECONDS:
FOR REMOTE LOCKING WITH HORN HONK CONFIRMATION, CONTINUE HOLDING THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
-- OR --
FOR REMOTE LOCKING WITHOUT HORN HONK CONFIRMATION, RELEASE THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
 - THE HORN WILL HONK CONFIRMING A REMOTE TRANSMITTER HAS BEEN LEARNED
- 4) TURN OFF THE IGNITION

NOTE: THE *KE106* HAS 4 REMOTE PROGRAMMING SLOTS, AND IT IS NECESSARY TO FILL ALL 4 SLOTS. IF USING 2 REMOTE TRANSMITTERS, IT IS NECESSARY TO PROGRAM EACH REMOTE TWICE.

MS2000 (SAA003T)

- 1) TURN THE IGNITION "ON"
- 2) PRESS AND HOLD THE OVERRIDE SWITCH
 - THE SIREN CHIRPS 5 TIMES AND LIGHT FLASHES 5 TIMES
 - THE STATUS LED WILL TURN ON SOLID
- 3) WITHIN 2 SECONDS:
FOR REMOTE LOCKING WITH CHIRP CONFIRMATION, CONTINUE HOLDING THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
-- OR --
FOR REMOTE LOCKING WITHOUT CHIRP CONFIRMATION, RELEASE THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
 - THE SIREN WILL CHIRP AND PARKING LIGHTS WILL FLASH ONCE CONFIRMING A REMOTE TRANSMITTER HAS BEEN LEARNED
- 4) TURN OFF THE IGNITION

NOTE: THE *MS2000* HAS 4 REMOTE PROGRAMMING SLOTS, AND IT IS NECESSARY TO FILL ALL 4 SLOTS. IF USING 2 REMOTE TRANSMITTERS, IT IS NECESSARY TO PROGRAM EACH REMOTE TWICE.

MS2004 (SAA004T)

- 1) TURN THE IGNITION "ON"
- 2) PRESS AND HOLD THE OVERRIDE SWITCH
 - THE SIREN CHIRPS 5 TIMES AND LIGHT FLASHES 5 TIMES
 - THE STATUS LED WILL TURN ON SOLID
- 3) WITHIN 2 SECONDS:
FOR REMOTE LOCKING WITH CHIRP CONFIRMATION, CONTINUE HOLDING THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
-- OR --
FOR REMOTE LOCKING WITHOUT CHIRP CONFIRMATION, RELEASE THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
 - THE SIREN WILL CHIRP AND PARKING LIGHTS WILL FLASH ONCE CONFIRMING A REMOTE TRANSMITTER HAS BEEN LEARNED
- 4) TURN OFF THE IGNITION

NOTE: THE *MS2004* HAS 4 REMOTE PROGRAMMING SLOTS, AND IT IS NECESSARY TO FILL ALL 4 SLOTS. IF USING 2 REMOTE TRANSMITTERS, IT IS NECESSARY TO PROGRAM EACH REMOTE TWICE.

MS2005 (SAA004T)

- 1) TURN THE IGNITION "ON"
- 2) PRESS AND HOLD THE OVERRIDE SWITCH
 - THE SIREN WILL CHIRP 3 TIMES
 - THE STATUS LED WILL TURN ON SOLID
- 3) WITHIN 2 SECONDS:
FOR REMOTE LOCKING WITH CHIRP CONFIRMATION, CONTINUE HOLDING THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
-- OR --
FOR REMOTE LOCKING WITHOUT CHIRP CONFIRMATION, RELEASE THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
 - THE SIREN WILL CHIRP AND PARKING LIGHTS WILL FLASH ONCECONFIRMING A REMOTE TRANSMITTER HAS BEEN LEARNED
- 4) TURN OFF THE IGNITION

NOTE: THE *MS2005* HAS 3 PROGRAMMING SLOTS, AND IT IS NECESSARY TO FILL ALL 3 SLOTS. IF USING 2 REMOTE TRANSMITTERS, IT IS NECESSARY TO PROGRAM 1 REMOTE TRANSMITTER TWICE.

MS2007 (SAA007T)

- 1) TURN THE IGNITION "ON-OFF-ON-OFF-ON"
 - THE SIREN WILL CHIRP ONCE
- 2) WITHIN 2 SECONDS, PRESS AND HOLD THE OVERRIDE SWITCH
 - THE SIREN WILL CHIRP 3 TIMES
 - THE STATUS LED WILL TURN ON SOLID
- 3) PRESS BUTTON 1 ON THE REMOTE TRANSMITTER
 - THE SIREN WILL CHIRP ONCE TO CONFIRMED IT LEARNED THE REMOTE TRANSMITTER

NOTE: THE *MS2007* HAS 2 PROGRAMMING SLOTS, AND IT IS NECESSARY TO FILL BOTH SLOTS. IF USING ONLY 1 REMOTE TRANSMITTERS, IT IS NECESSARY TO PROGRAM THE REMOTE TWICE INTO THE SYSTEM. IF USING 2 REMOTE CONTROLS, PROGRAM EACH REMOTE TRANSMITTER ONCE.

RS131 / RS151 (SAA004T)

- 1) TURN THE IGNITION "ON"
- 2) PRESS AND HOLD THE OVERRIDE SWITCH
 - THE HORN HONKS 5 TIMES AND LIGHT FLASHES 5 TIMES
 - THE STATUS LED WILL TURN ON SOLID
- 3) WITHIN 2 SECONDS:
FOR REMOTE LOCKING WITH HORN HONK CONFIRMATION, CONTINUE HOLDING THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
-- OR --
FOR REMOTE LOCKING WITHOUT HORN HONK CONFIRMATION, RELEASE THE OVERRIDE SWITCH AND PRESS TRANSMITTER BUTTON 1
 - THE HORN WILL HONK CONFIRMING A REMOTE TRANSMITTER HAS BEEN LEARNED
- 4) TURN OFF THE IGNITION

NOTE: THE *RS131 / RS151* HAS 3 REMOTE PROGRAMMING SLOTS, AND IT IS NECESSARY TO FILL ALL 3 SLOTS. IF USING 2 REMOTE TRANSMITTERS, IT IS NECESSARY TO PROGRAM EACH REMOTE TWICE.