

**CeNET**

# — SYSTEM CHART —

## MULTIMEDIA



**VRX776VD**  
DVD MULTIMEDIA STATION  
WITH CeNET & 7-INCH  
TOUCH PANEL CONTROL



**MAX676VD**  
2-DIN DVD MULTIMEDIA STATION  
WITH CeNET & 7-INCH  
TOUCH PANEL CONTROL

## MULTIMEDIA



**VRX576USB**  
DVD MULTIMEDIA STATION  
WITH 7-INCH  
TOUCH PANEL CONTROL



**VRX376USB**  
DVD MULTIMEDIA STATION  
WITH 3.5-INCH MONITOR

## DVD RECEIVER

**VB476**

DVD/CD/VCD/MP3/  
WMA RECEIVER



## PROCESSOR

**DVH940**

DOLBY DIGITAL/  
dts/ CeNET  
PROCESSOR



**DVC920**

DOLBY DIGITAL/  
dts CeNET  
PROCESSOR CONTROLLER



## DVD CHANGER

**VCZ625**

6-DISC DVD/CD/  
VCD/MP3  
CeNET CHANGER



## CD CHANGER

**DCZ625**

6-DISC CD CeNET  
CHANGER



**DC625**

6-DISC CD C-BUS  
CHANGER



## iPod® INTERFACE

**EA1251**

iPod Connecting Unit for  
'06 CeNET Models



**EA1276**

iPod Connecting Unit for  
'07 CeNET Models



## MAIN UNITS



**HX-D2**

CD RECEIVER/CeNET CONTROL



**VXZ766**  
DVD/CD/VCD/MP3/WMA  
RECEIVER/  
CeNET CONTROL



**VXZ756BK**  
DVD/CD/VCD/MP3/WMA  
RECEIVER/  
CeNET CONTROL



**DXZ776USB**  
CD/USB/MP3/WMA/AAC  
RECEIVER/  
CeNET CONTROL



**DXZ676USB**  
CD/USB/MP3/WMA/AAC  
RECEIVER/  
CeNET CONTROL



**DXZ576USB**  
CD/USB/MP3/WMA/AAC  
RECEIVER/  
CeNET CONTROL



**DXZ476MP**  
CD/MP3/WMA RECEIVER/  
CeNET CONTROL



**DXZ376MP**  
CD/MP3/WMA RECEIVER/  
CeNET CONTROL



**DXZ276MP**  
CD/MP3/WMA RECEIVER/  
CeNET CONTROL



**DB566USB**  
CD/USB/MP3/WMA RECEIVER



**FB276BT**

Bluetooth SD/MP3 RECEIVER



**DUB276MP/276MPW**  
2-DIN CD/USB/MP3/WMA  
RECEIVER



**DB176MP**

CD/MP3/WMA RECEIVER



**DFZ667MC**  
2-DIN CD/SD/MP3/WMA  
RECEIVER/CeNET CONTROL



**WXZ466MP**  
2-DIN 6-DISC CD /MP3/WMA  
RECEIVER/CeNET CONTROL

**C-BUS**



**AX430**  
CASSETTE RECEIVER/  
C-BUS CONTROL



**ARX1970**  
CASSETTE RECEIVER/  
C-BUS CONTROL

## TV TUNER



**TTX754/TTX7501z/  
TTX7503z**  
CeNET TV TUNER

## Bluetooth®



**BLT370**  
Bluetooth AUDIO/  
MOBILE-PHONE  
TRANSCIVER  
FOR AUX INPUT

## MAIN UNITS



**DB346MPV**  
CD/VCD/MP3 RECEIVER



**DB166**  
CD RECEIVER



**ADB341MP**  
2-DIN CD/MP3/  
CASSETTE RECEIVER