



## Product Bulletin

PB00001

<b>Category:</b>	<b>Multimedia</b>	<b>Date:</b>	<b>2/15/05</b>
<b>Subject:</b>	<b>VRX755VD and iPod interface (CCA649)</b>		

**NOTE:** The VRX755VD with the CCA649 (iPod interface cable) is only compatible with the following Apple iPods:

- Third Generation, Version 2.2
- Forth Generation, Version 3.01/3.02
- iPod Mini, Version 1.2

(iPod with versions other than stated above may not operate and/or operate improperly. First and second generation iPods are not compatible.)

### Apple iPod Operation:

- Once the iPod is connected to the CCA649 cable, select the iPod mode by either pressing the (SOURCE) button or by touching the iPod icon on the source menu. (When the iPod is connected to the CCA649, the iPod buttons are disabled.)
- When the VRX755VD is in iPod mode, a special “iPod” menu will appear on the screen.
- The VRX755VD can display the song title, artist name, and album title of tracks recorded on the iPod. When no track data is present, the title display will remain blank.
- If the VISUAL AUX SENS setting is changed during visual mode, the playback volume during iPod mode will be adjusted on the VRX755VD.
- While the iPod is connected to the CCA649, the equalizer function is turned OFF.
- The remote control for the VRX755VD cannot be used to perform scan, repeat or random play functions.

### 2-Zone Function:

- If Visual mode is selected for Sub Zone, the 2-Zone function will be cancelled when the iPod is connected.
- When the iPod is connected, playback is supported only when Sub Zone is set to DVD mode.
- When connecting the iPod, the iPod mode can only be selected in the Main Zone, regardless of the ON/OFF setting of the 2-Zone function.

### Precautions: Regarding battery consumption:

When the iPod’s internal battery becomes depleted, the recharge warning indicator will appear on the iPod’s display. In this condition, the iPod can no longer used until the battery is recharged.

Note: The VRX755VD does not recharge the internal battery of the iPod.